



**BABYBELLE**

## **BLENDER with GRINDER**



<b>Model No.</b>	<b>BBC02</b>
<b>Specification</b>	<b>220-240V~50-60Hz 200W</b>
<b>Capacity</b>	<b>Blender Jar      500ml</b>
	<b>Grinder Jar      350ml</b>


## **IMPORTANT SAFEGUARDS**

**When using electrical appliances, safety precautions should be followed, including the following:**

- i) Read all instruction carefully, even if you are familiar with appliance.**
- ii) To protect against the risk of electric shock DO NOT IMMERSE the appliance, cord set or the plug in water or any liquid.**
- iii) To clean, wipe exterior with a damp cloth.**
- iv) Close supervision is necessary when any appliance is operated near children. The appliance must not be used by children.**
- v) The appliance must always be unplugged when not in use and before cleaning or maintenance.**
- vi) Do not operate any appliance with damaged cord or plug, or if appliance malfunctions or is damaged in any manner.**
- vii) Handle sharp blender blades carefully to avoid cuts and injuries.**
- viii) This appliance is designed for indoor use only.**
- ix) Do not allow cord to hang over edge of table or counter, or touch hot surface.**
- x) Do not place unit on or near a gas or electric burner or a heated oven.**
- xi) Do not use appliance for mixing paints or other flammable liquids or in a location contaminated with flammable gases or vapours.**
- xii) Do not leave the appliance unattended. Do not use the appliance for other than its intended use.**
- xiii) Do not use abrasive cleaners or scouring pad on appliance.**
- xiv) Ensure switch off the unit after each use. Make sure the motor stops completely before disassembled.**
- xv) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**
- xvi) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
- xvii) Children should be supervised to ensure that they do not play with appliance.**
- xviii) Ensure that the blender is switch off before removing it from the stand.**
- xix) Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.**
- xx) Care is needed when handling cutting blades, especially when removing the blade from the bowl, emptying the bowl and during cleaning.**

**SAVE THIS INSTRUCTIONS**

## 1. Name of each parts



## 2. Function of blender

### 1. crush up(one blade) :

- Be able to crush up coffee bean, dried fish, Soya bean, gingerli and such kind of hard food, and can keep the original nutrition constituent

### 2. mix(cross blade) :

- Can mix fruit, vegetable etc.,

### 3. healthy drink :


- Using various kinds of food for making can make various kinds of healthy drink.

### **3. Feature of blender**

1. convenient operation
  - Do not use other container but directly use the one of this blender for storage or drink
  - According to the specialty of the food, use one blade or cross blade and choose to use big or small container
  - Convenient for cleaning, after usage, pour rinsing and then blank run will be OK.
2. wonderful feature design and solid performance
  - Wonderful feature design makes the blender can match with the surroundings in any rooms, and this blender have nice anti-temperature, anti-pulse because of using new pattern of material.
3. multi-performance
  - This blender have string, crushing.. Mixing and musing and more other performances with the main purpose of absorbing nutrition conveniently and immediately.
4. The quality management and after-sale service for the focus of customer.
  - Safety: The complete separate design between blades and mechanical body makes everybody can operate the blender safely.
  - Use high-performance motor: Due to use high-performance motor, any food can be crushed quickly. When over-loaded, the protector will be effected, which can ensure safe.
  - Perfect after-sale service can make you without the worries behind

### **4. Usage method**


1 · Open the container by hand just like the image makes them separate.




2 · Put food into the container.




3 · According to the type of the food for choosing the type of blade.




4 · Close clockwise the rotate base to the container




5 · Put the contact head of container face to the groove of mechanical body, press down slightly and rotate it clockwise, the blade is in the status of rotation at this moment.




6 · When crush harder food or the food with little water, in order to prevent the blade blank run, you can catch hold of the container and mechanical body with both hands and then shake them up-to-down and left-to-right slightly, which can make the food crush for short time.



7. After finishing adjustment, catch hold of the container and rotate it anti-clockwise to make the mouth upward, and then catch hold of the rotate base, rotate anti-clockwise to make the container separate from the rotate base.



8 · Use the container cover to cover it tightly and then put into icebox for storage.



## 5. Notice

i) **Do not operate the blender longer than 1 min. at one time. Stop and cool at least 1 min. then resume.**

ii) Do not switch on your blender if the jar is empty. The cutter bearing may be damaged if run on “No Load”.

iii) Do not put into excessive food, standard : “ Solid food 80g , liquid food 350ml”.


## 6. Clean and maintenance

1 · After usage, put little water into container, and then let it blank run for 10 seconds, the purpose of cleaning will be achieved accordingly.

2 · After usage, put neutral ambulant into warm water, wipe with soft flax, prohibit with iron brush.



3 · While cleaning, do not make the mechanical body dip in water or make water get into the inner of mechanical body.




4 · Wipe the rotate base to dry and clean, when completely done, you can store it accordingly.



## 7. procedure direction

1 · Continuous operation: put the container full of food face to the groove of mechanical body and press slightly, and then rotate the container clockwise to be tight.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

**Manufacturer : Tai Yu ( Dongguan ) Electrical Co., Ltd.  
Dong Xing Industrial Park, Dong Keng Town,  
DongGuan City, Guang Dong Province,  
China.**